


How to disassemble and reassemble AD series Din unit.



1) Remove white terminal cover as illustrated above.

2) Remove unit from enclosure. Catches on both side of unit, only one side illustrated above.



3) Remove 1 x centre screw from front.

4) Remove one screw holding PCB.

Unit can now be unfolded to carry out any changes.

- Care should be taken to keep all the screws and washers.
- To reassemble follow the above steps in reverse order.