



NOTES:

- 1) The rack is shown with nine units fitted and one unused position
- 2) Connector assemblies shown in the unused positions are normally only fitted when that position is expected to be occupied. Unused positions always have a blanking plate fitted to maintain RFI integrity.
- 3) 180mm should be left at the front of the rack to allow for unit withdrawal.

<div>DIMENSIONS in mm</div> <div>TOLERANCES ±</div> <div>Nominal 0.4 mm</div> <div>Decimal 0.15 mm</div> <div>Unless shown otherwise</div>	Drawn: SG		Title: AH Surface Enclosure - RIS 5300-11 Replacement		<div>AMELEC INSTRUMENTS</div> <div>Cochran Close, Presley Way</div> <div>Crownhill, Milton Keynes, MK8 0AJ</div>	
	Checked: DM		Views of enclosure showing major dimensions.			
	Approved:		Used on Assembly	SCALE	DRAWING NO.	Sht 1
	Date: 08/05/2014		AH-RIS Product Series	N.T.S.	AH-RIS Surface Rack	of 1